

2.3.1 Joint frame mode

The Joint frame mode is for operating the robot by controlling the joint positions. After you select **Joint** for the Mode, when a standard SCARA robot is connected, the controllable axes are J1 to J4; when a VA robot (articulated robot) is connected, the controllable axes are J1 to J6.

Mode

Mode :

Joint

User Frame ID :

0

Tool Frame ID :

1

