

On the other hand, you can open the **JOG** subpage and select **Joint** for the Mode, and the unit is “deg” by default. You can switch the unit to “puu” as required <sup>\*Note</sup>. The following examples are based on the operation screen when a VA robot is connected.

Note: PUU (Pulse of User Unit) is a unit scaled by the E-Gear ratio.

