

Select **Tool** for the Mode. In the Tool frame mode, you can move the robot by setting the User Frame ID and Tool Frame ID to the ID numbers with the corresponding frames established *Note. The default settings are both 0.

Mode

Mode : Tool

User Frame ID : 0

Tool Frame ID : 0

On the other hand, you can open the **JOG** subpage and select **Tool** for the Mode, and then set the UF and TF to the ID numbers with the corresponding frames established.

JOG subpage for SCARA	JOG subpage for VA
JOG Setting Mode : Tool Distance : Max UF: 0 TF: 0 ☒ Continuous Posture H: 0 JRC4: 0 JRC5: 0 Operator X: 260.156 mm Y: -400.166 mm Z: -60.000 mm RZ: -124.690 deg 	