

2.5 JOG subpage

Click  (Switch for Subpage) to open the Subpage and choose the **JOG** tab. In this tab, the operating personnel can move the robot, access the position data, and switch between modes.

JOG

Setting

Mode :

User

UF: 0

TF: 0

Distance :

Max

[mm]/[deg.]

☒ Continuous

Posture

E: 0 S: 0 F: 0 JRC4: 0 JRC6: 0

Operator

X: 677.949 mm RX: 165.702 deg

Y: 315.876 mm RY: -13.457 deg

Z: 444.200 mm RZ: 47.387 deg

Area	Description
Setting	For switching the coordinate frames (modes), frame IDs, and setting the moving distance. Refer to Section 2.5.1 for details.
Posture	Shows the postures of the robot at present. Refer to Section 2.5.2 for details.
Operator	Shows the axis positions of the robot at present and the operation buttons for controlling the axis moving directions. Refer to Section 2.5.3 for details.

2-16