

2

- Discontinuous: there is a limit on the moving distance of each robot movement. Click  and  to adjust the setting or directly enter the value. When the setting value exceeds the maximum limit, the distance is automatically set to the maximum limit; on the contrary, the distance is automatically set to the minimum limit.

Joint frame mode		World / User / Tool frame mode
Distance : 1.000 [Degree] ☐ Continuous	Distance : 1000 [PUU] ☐ Continuous	Distance : 1.000 [mm]/[deg.] ☐ Continuous
Default setting: 1 Setting range: 0.01 - 20		Default setting: 1 Setting range: 0.001 - 20