

7

Homing (Home)

7.1	Go Home	7-2
7.2	Z index	7-3
7.3	Hardware Limit	7-4
7.3.1	J4 & J6 axes	7-5
7.3.2	Hardware limit posture	7-6

8

Arm

8.1	Arm	8-2
8.2	Payload	8-4
8.2.1	Setting the Mass	8-4
8.2.2	Setting the Distance	8-5
8.2.3	Setting the Inertia	8-6
8.2.4	Calculating the inertia	8-7
8.3	Lead & Collision	8-8
8.3.1	Collision Setting	8-8
8.4	Gravity	8-9
8.4.1	Descriptions of Gravity parameters	8-10
8.4.2	How to use the Gravity function	8-11

9

Robot Information (Info)

9.1	Info	9-2
9.2	Temperature	9-3
9.3	Controller	9-4
9.4	Alarm History	9-5
9.5	About	9-5
9.6	RL User Log	9-6
9.6.1	User Log instructions	9-7
9.6.2	How to use the User Log function	9-8

10

System

10.1	EtherNet IP	10-2
10.2	RS232/485	10-3
10.3	Language	10-4
10.4	Backup	10-5
10.5	Recovery	10-6
10.6	Options	10-7