

4

- Click **Save** to save the modified data. The row is no longer highlighted, indicating that the data has been saved.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RY (degree)	RZ (degree)	Hand	UserID	ToolID	Coordinate	Coordinates
1001	☒	p1001	213.740	202.111	0.000	0.000	0.000	1	0	0	1	
1002	☐	p1002	213.740	202.111	0.000	0.000	-292.437	1	0	0	1	
1003	☐	p1003	0.000	0.000	0.000	0.000	0.000	0	0	0	1	
1004	☐	p1004	380.306	57.522	-51.791	-65.720	-189.740	1	0	0	1	
1005	☐	p1005	0.000	0.000	0.000	0.000	0.000	0	0	0	1	

Local Point

Add Clear

Delete **Save**

Motion Command(mm)

Please choose one point

File: Local Teach ☐ Check All

Name: p1001

Motion: MovP Ext Teach Go

Maximum Top 0

Rise height 0

Drop height 0

4.2.4 How to perform the lift motion

- In the Point management page, select the target point to be reached through the Lift motion.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RY (degree)	RZ (degree)	Hand	UserID	ToolID	Coordinate	Coordinates
1001	☐	p1001	213.740	202.111	0.000	0.000	0.000	1	0	0	1	
1002	☐	p1002	213.740	202.111	0.000	0.000	-292.437	1	0	0	1	
1003	☐	p1003	0.000	0.000	0.000	0.000	0.000	0	0	0	1	
1004	☒	p1004	380.306	57.522	-51.791	-65.720	0.000	1	0	0	1	
1005	☐	p1005	0.000	0.000	0.000	0.000	0.000	0	0	0	1	

- Input the parameters as needed in the Lift Motion area of the **Point** subpage.

Point

Lift Motion

Orientation (degree): 45.000

Deg. (degree): 45.000

Height (mm): 10.000

- Select **Lift** for the Motion in the Motion Command area, and then press and hold **Go** to have the robot move according to the settings in the previous step.

Motion Command(mm)

Please choose one point

File: Global Teach ☐ Check All

Name:

Motion: Lift MovP MovL **Lift** Ext Teach **Go**

- For the detailed parameter settings for the Lift motion, refer to the description of the Lift motion type in Section 4.1.