

4.2.6 How to set the axis rotation mode

1. In the Point management page, select the check box in the Check column for the point you want to change its JRC_Active setting (axis rotation mode).

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (degree)	Hand	UserID	ToolID	Coordinate	CoordinateStr	J4_JRC	JRC_Active
1001	☐	p1001	400.000	0.000	0.000	-180.762	0	0	0	1	User	1	4
1002	☐	p1002	324.555	-1.334	-145.257	35.532	0	0	0	1	User	0	4
1003	☐	p1003	0.000	0.000	0.000	0.000	0	0	0	1	User	0	4
1004	☒	p1004	343.888	25.007	-7.622	0.000	0	0	0	1	User	0	4
1005	☐	p1005	0.000	0.000	0.000	0.000	0	0	0	1	User	0	4

2. Select the desired mode in the JRC Operate area of the **Point** subpage, and then click **Active**.

Point

JRC Operate

2 : Select Near Path

Active

There are four modes (0: disable the axis rotation mode). Refer to Section 4.3.2 JRC_Active (axis rotation mode) for details.

File Operate

0 : JRC Inactive

1 : JRC Active

2 : Select Near Path

3 : Select Near Path & Avoid Joint Limit

4 : Directly motion by value

0 : JRC Inactive

Active

3. Then, the JRC_Active setting is successfully changed.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (degree)	Hand	UserID	ToolID	Coordinate	CoordinateStr	J4_JRC	JRC_Active
1001	☐	p1001	400.000	0.000	0.000	-180.762	0	0	0	1	User	1	4
1002	☐	p1002	324.555	-1.334	-145.257	35.532	0	0	0	1	User	0	4
1003	☐	p1003	0.000	0.000	0.000	0.000	0	0	0	1	User	0	4
1004	☒	p1004	343.888	25.007	-7.622	0.000	0	0	0	1	User	0	2
1005	☐	p1005	0.000	0.000	0.000	0.000	0	0	0	1	User	0	4