

4.4 Local points

Each project stores its own local points. The ID of local points ranges from 1001 to 7000, which means up to 6,000 local points can be saved in one project. Refer to Section 4.3 Point data for details.

Local

	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (degree)	Hand	UserID	ToolID	CoordinateStr	J4_JRC	JRC_Active
1001	☐	p1001	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1002	☐	p1002	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1003	☐	p1003	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1004	☐	p1004	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1005	☐	p1005	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1006	☐	p1006	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1007	☐	p1007	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1008	☐	p1008	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1009	☐	p1009	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1010	☐	p1010	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1011	☐	p1011	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1012	☐	p1012	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1013	☐	p1013	0.000	0.000	0.000	0.000	0	0	0	User	0	4
1014	☐	p1014	0.000	0.000	0.000	0.000	0	0	0	User	0	4

Local Point

Add Clear

Delete Save

Motion Command(mm)

Please choose one point

File: Local

Name: p1020

Motion: MArchP

Teach

Ext Teach

Go

☐ Check All

Maximum Top: -10

Rise height: 30

Drop height: 50

Local tab in Point management page

4.5 Global points

The global points are stored in the internal memory of the controller and shared by all projects. The ID of global points ranges from 1 to 1000, which means up to 1,000 global points can be saved in the controller. Refer to Section 4.3 Point data for details.

Global

	Check	Name	X (mm)	Y (mm)	Z (mm)	RZ (deg.)	Hand	UserID	ToolID	CoordinateStr	J4_JRC	JRC_Active
1	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
2	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
3	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
4	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
5	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
6	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
7	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
8	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
9	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
10	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
11	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
12	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
13	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0
14	☐		0.000	0.000	0.000	0.000	0	0	0	MCS	0	0

Global Point

Refresh Clear

Motion Command(mm)

Please choose one point

File: Global

Name: GL_1

Motion: MArchP

Teach

Ext Teach

Go

☐ Check All

Maximum Top: -10

Rise height: 30

Drop height: 50

Global tab in Point management page