



Chapter 4: Interface Function

SOURCE & AMB. TEMP PROBE Ports

The SOURCE and AMB. TEMP PROBE ports can detect source temperature and ambient temperatures respectively. The ADU functions according to the different source and ambient temperatures. Please see the tables below for detailed description.

- **SOURCE TEMP PROBE Port:**

Source Temperature ^{*3}	ADU Status
< 20°C	1. All fans turn on. 2. Fan-status LED indicator: Off 3. Min. fan speed (Duty cycle: 20%)
20°C~25°C	1. All fans turn on. 2. Fan-status LED indicator: Off 3. The temperature alarm goes off. The actual alarm depends on user's application of dry contact (Pin 2)^{*4}. 4. Min. fan speed (Duty cycle: 20%)
> 25°C	1. All fans automatically turn off. 2. Fan-status LED indicator: Red 3. Both temperature and fan alarms go off. The actual alarms depend on user's application of dry contact (Pin 2 & Pin 3)^{*4}.

^{*3}: The operating temperature is 10°C~20°C.

^{*4}: Please see **Chapter 4** for dry contact information.