



Chapter 1: Important Safety Instructions

Safety Warnings

- Before installation:
 - Ensure that the power cord plug and socket are in good condition.
 - Check whether all fans (6 PCS) inside the Air Distribution Unit (ADU) are securely in place.
 - Disconnect power to the ADU. Failure to do so may result in personal injury or damage to equipment.
- The ADU contains moving parts, which are potentially hazardous. Do not apply power to the ADU until installation is complete.
- Keep fingers and clothing away from fans. When the ADU is powered on, the moving parts might cause personal injury.
- Use the provided input power cord to connect the ADU and power source. The power supply to the ADU must be rated between 100~240Vac. The installation of a protective device such as fuse or circuit breaker is highly suggested.
- Do not attempt to disassemble the ADU. It contains potentially hazardous voltages.
- Always follow this User Manual to install and operate the ADU.

Usage Warnings

- Only install the ADU under a raised floor. Do not put any object, enclosure or cabinet on the raised floor that might hinder cool air supply.
- Make sure the ADU is installed under the raised floor and is located in front of the cabinets or enclosures containing the electronic equipment that needs cooling.