


No.	Item	Description
1	 PWR-SW	This is the power switch to turn on/ off the ADU.
2	 PWR-LINE	This is the input socket. Please follow safety rules to choose either the provided CE or UL power cord.
3.1	20°C~27°C  PWM-Max. SETUP	DIP switch function illustration: 1. 20°C~27°C: To set the ambient temperature range 2. PWM-Max ^{*2} : To set the fan speed
3.2	 SETUP	The DIP switch sets the fan speed in different ranges of ambient temperatures. Please see Chapter 4 'Dip Switch' for detailed description.
4	FAN  STATUS	Fan-status LED indicator: 1. LED Off: when fans are normal 2. LED On (Red): when fans are abnormal
5	SYSTEM  STATUS	System-status LED indicator: 1. LED On (Green): when system is normal 2. LED Flashes (Green): when over voltage occurs 3. LED Off: when short circuit occurs
6	SOURCE  TEMP-PROBE	This port connects a 1-M long temperature cable (provided) to detect the source temperature. Please see Chapter 4 'SOURCE & AMB. TEMP PROBE Ports' for detailed description.
7	AMB  TEMP-PROBE	This port connects a 3-M long temperature cable (provided) to detect the ambient temperature. Please see Chapter 4 'SOURCE & AMB. TEMP PROBE Ports' for detailed description.
8.1	 DRY-CONTACT	This 5-Pin output connector monitors the ADU and its surrounding environment. Please see Chapter 4 'Dry Contact' for detailed description.
8.2	 DRY-CONTACT	Dry-contact 5-Pin function illustration: Pin 1: SYSTEM STATUS / Pin 2: TEMP. STATUS Pin 3: FAN STATUS / Pin 4: HIGH-TEMP. ALARM / Pin 5: RETURN-SIG Please see Chapter 4 'Dry Contact' for detailed description.

*2: PWM = Pulse-width modulation