

No.	Item	Description
①	Network Port	Connected to the Ethernet Network.
②	LED Indicators	When the Mini SNMP is initializing or upgrading the firmware, the two LED indicators flash simultaneously to show its status. • Rapid simultaneous flashing (every 50ms): Initialization or firmware upgrade is in progress. • Slow simultaneous flashing (every 500ms): Initialization failed.  WARNING: Do NOT remove the Mini SNMP or disconnect the UPS's input power during initialization or firmware upgrade! This could result in data loss or damage to the Mini SNMP. The green LED indicator shows the network connection status. • ON: Network connection has been established and the IPv4 address is useable. • OFF: Not connected to a network. • Flashing slowly (every 500ms): Faulty IP address. The yellow LED indicator shows the connection status between the Mini SNMP and the UPS. • Flashing rapidly (every 50ms): UPS connected. • Flashing slowly (every 500ms): UPS not connected.
③	Console (COM) Port	1. Connected to a workstation with the provided RJ45 to DB9 cable to configure the system. 2. Connected to an EnviroProbe (optional) to monitor the EnviroProbe's connected environment monitoring devices.

**NOTE:**

For EnviroProbe information, please refer to the Installation Guide included in the package of the EnviroProbe.