

Chapter 4 : System Configurations

There are different ways you can configure your Mini SNMP. If a network connection is available at your location, the following methods can be used.

- **Web-based interface:** The InsightPower G3 Mini SNMP for UPS Web supports comprehensive system management and monitoring. Please refer to **4-1 Configuring via InsightPower G3 Mini SNMP Web** and **Chapter 5: InsightPower G3 Mini SNMP for UPS Web**.
- **EzSetting:** Use the provided program EzSetting to quickly set up your Mini SNMP. Please refer to **4-2 Configuring with EzSetting**.
- **Telnet mode:** Configure your Mini SNMP in text mode. Please refer to **4-3 Configuring via Telnet**.

Alternatively, you can also set up your Mini SNMP by direct COM port connection. Please refer to **4-4 Configuring through COM Port**.



NOTE :

1. To ensure system security, it is highly recommended that you change your account and password after the first login.
2. If you have multiple Mini SNMP units installed in your network, we highly suggest that you change the Mini SNMP's default Host Name to avoid conflicts. Also, it is recommended that you disable BOOTP/ DHCP and manually assign a valid static IP address to the Mini SNMP.

4-1 Configuring via InsightPower G3 Mini SNMP Web

To set up the Mini SNMP via your web browser, please follow the instructions below:

- Step 1** Plug a CAT5 network cable into the Mini SNMP's network port to connect to the network. Then, launch your web browser. In the address bar, enter the Mini SNMP's default Host Name **InsightPower** or default IP Address **192.168.1.100**. If you are unable to connect, please see **Chapter 7: Troubleshooting Q6**.