

Information

Go to **Monitor** → **Environment** → **Information** to see your EnviroProbe's Sensor Information, Input Contacts and Contact Setting.



Configuration

Go to **Monitor** → **Environment** → **Configuration** to configure your EnviroProbe's Warning Threshold, Alarm Threshold, Title and Type.



5-1-4 About

Under the About category, there is only one item, Information.

Information

Go to **Monitor** → **About** → **Information** to see the version of your InsightPower G3 Mini SNMP and other information about OpenSSL toolkit and licenses.