

- **Voltage Sensitivity**

After you set up your voltage sensitivity (there are Normal, Reduced, and Low selections) and click **Submit**, the Mini SNMP will send the command to the UPS to enable the UPS's voltage sensitivity function.

- **Transfer Voltage**

After you click **Submit** to confirm your transfer voltage setup, the Mini SNMP will send the command to the UPS to enable the relevant functions.

- **Low Battery**

After you set as Enable, the Mini SNMP will save the setup value and compare with the values received from the UPS. If the received battery level is lower than the setup value, the Mini SNMP will issue a low-battery alarm.

- **Battery Replacement Date**

After you set up battery replacement dates, the Mini SNMP will send the command to the UPS and save the information in the UPS.

- **Bypass Transfer Frequency**

After you set a tolerance of bypass transfer frequency and confirm your setup, the Mini SNMP will send the command to the UPS. If the UPS transfers to bypass mode and the bypass frequency is out of the tolerance, output will be turned off and critical loads will be protected.

- **Periodic Auto Test**

This configuration is to set up the battery test time. After you confirm your setup, the Mini SNMP will send the command to the UPS and save the setting in the UPS. When the test time is due, the UPS will automatically perform the battery test.

- **Customized Battery Test**

The configuration is to set up the battery test parameters, which will be stored in the UPS EEPROM. To perform the customized battery test, go to **Control** → **Battery Test** and select **Customized Battery Test**.

- **Economic Mode**

After you click **Submit** to confirm your economic mode setup, the Mini SNMP will send a command to the UPS to enable/ disable the relevant functions.