



Event Level

Go to **Device** → **Management** → **Event Level** to set up an event level for the UPS or Environment Sensor. If you want to receive an event notification, please refer to **5-3-3 Notification - SNMP Trap** and **5-3-3 Notification - Mail Server**.

UPS

You can select an event level (**None**, **Information**, **Warning** and **Alarm**), and once a UPS event occurs, the event will be sent according to this level setting.



Environment Sensor

You can select an event level (**None**, **Information**, **Warning** and **Alarm**), and once an Environment Sensor event occurs, the event will be sent according to this level setting.