

Q10. What to do if I forget Administrator's account and password?

You can reset Administrator's account and password via text mode. Refer to **4-4 Configuring through COM Port** to establish a COM port connection with the Mini SNMP. When you are prompted by the login window, key in **rstadmin** within 60 seconds and press **enter**. The Administrator account and password are now reset to default (admin/ password).

Q11. How to test SNMPv3 in Linux?

Before you can access the SNMP OID (Object Identifier) via SNMPv3 protocol, the SNMPv3 USM table must be organized. Please refer to **5-3-2 Service** for more information.

To test SNMPv3 in Linux, launch shell and key in the following command.

```
snmpwalk -v 3 -u <user> -l authPriv -A <password> -X <password> -n <context name> -t 3 <ip>
1.3.6.1.2.1.1.1.0
```

-v: 1 for SNMPv1, 3 for SNMPv3.

-u: The user name which is assigned from SNMPv3 USM table.

-l: Followed by the security levels. They are: noAuthNoPriv, authNoPriv and authPriv.

-A: The Auth Password which is assigned from SNMPv3 USM table.

-X: The Priv Password which is assigned from SNMPv3 USM table.

-n: The Context Name which is assigned from SNMPv3 USM table.

-t: Timeout in seconds.

<ip>: The IP address of the Mini SNMP.

<oid>: The next available SNMP OID (for example: 1.3.6.1.2.1.1.1.0). Please refer to the RFC1213 MIB.