

Chapter 1 : Important Safety Instructions

1-1 Warnings

- The InsightPower G3 Mini SNMP Card, hereafter referred to as Mini SNMP, is designed to work with a UPS and needs to be installed inside the UPS's Mini slot. Before installation, ensure that all power sources and critical loads connected to the UPS are disconnected.
- Do not place or use this unit in the presence of flammable substances.
- Do not attempt to disassemble the unit.
- Do not attempt to perform any internal modifications on the unit.
- Do not attempt to fix/ replace internal components. When repair is needed, refer all servicing to the nearest Delta service center or authorized distributor.
- Do not allow any objects or liquids of any kind to penetrate the unit.
- Always follow this User Manual to install and operate this unit.

1-2 Standard Compliance

- **EN 55032: 2015 ISN, Class B**
- **EN 55032: 2015 Radiated Emission, Class B**
- **EN 55024: 2010 + A1: 2015**
 - IEC 61000-4-2: 2008
 - IEC 61000-4-3: 2010
 - IEC 61000-4-4: 2012
 - IEC 61000-4-6: 2013
- **UL 62368-1 & CAN/CSA C22.2 No. 62368-1-14**
- **EN 62368-1: 2014/ A11: 2017**