

Table of Content

Chapter 1 : Important Safety Instructions	5
1.1 Installation Warnings.....	5
1.2 Connection Warnings.....	5
1.3 Usage Warnings.....	6
1.4 Storage Warnings	8
1.5 Standard Compliance	8
Chapter 2 : Introduction	9
2.1 Product Introduction.....	9
2.2 PQC Series Mixed Fixed type APF Product Category.....	10
2.3 Functions & Features.....	12
2.4 Product Structure and Appearance.....	13
2.4.1 HMI Display.....	13
2.4.1 Module Exterior & Dimensions	22
2.5 Inspection.....	23
Chapter 3 : Operation Modes	25
3.1 Pre-installation Confirmation.....	25
3.2 Installation Environment.....	25
3.3 APF Cabinet Unpacking and Hoisting	27
3.3.1 Unpacking APF Cabinet.....	27
3.3.2 Hoisting APF Cabinet.....	29
3.4 APF Cabinet Wiring	29
3.5 Module Installation	31
3.5.1 APF Module Structure.....	31
3.5.2 Pluggable terminals	34
3.5.3 HMI Display Structure	38
3.5.4 Module Installation and Wiring.....	40
3.6 Load Current Detection for CT Installation and Wiring	45
3.6.1 CT Selection.....	45
3.6.2 Basic CT Installation & Wiring.....	46
Chapter 4 : APF Operation Procedure.....	48
4.1 Inspection Before Start-up	48