

Item	Description	Item	Description
①	The " Home " button. Click to go back to the home page.	⑧	Indicate wiring type, 3P3W / 3P4W. Indicate voltage sequence, + is Positive, - is Negative
②	Indicate the CT Position setting.	⑨	Indicate system status, Run, Standby, ECO or Fault.
③	Indicate quantity of modules connected to this HMI.	⑩	The " Login " button. Click to show the pop-up log-in window. Please enter the correct user name and password to proceed to the operation of a higher level.
④	The " Event Log " button. Click the button to go to the " Event Log " screen that displays history events of the device.	⑪	The " Grid " button. Click to show the corresponding detailed information.
⑤	The " Menu " button. Click to show the first level menu on the HMI.	⑫	The " Load " button. Click to show the corresponding detailed information.
⑥	Displays the time of the system.	⑬	The " PQC " button. Click to show the corresponding detailed information.
⑦	Displays the working mode. (Ex: compensator, source).	⑭	The " ON/ OFF " button. Click to turn on/ off the PQC system.