

- You must contact Delta customer service if any of the following events occurs:
 1. Any liquid is poured or splashed on the APF.
 2. The APF is deformed.
 3. Any conductive powders or metals enter into the APF.
 4. The APF does not run normally after you carefully followed the instructions in this ***User Manual***.

1.4 Storage Warnings

- Use the original packing materials to pack the APF to prevent any possible damage from rodents.
- If the APF needs to be stored prior to installation, it should be placed in a dry indoor area. The allowable storage temperature is -40°C ~ 70°C (-40°F ~ 158°F) and the relative humidity is within 95% (non-condensing).
- If the HMI needs to be stored prior to installation, it should be placed in a dry indoor area. The allowable storage temperature is -30°C ~ 70°C (-22°F ~ 158°F) and the relative humidity is within 95% (non-condensing).

1.5 Standard Compliance

- IEC 62477-1:2016 Safety requirements for power electronic converter systems and equipment, Part 1: General
- IEC 61000-6-2:2016 Electromagnetic compatibility (EMC) Part 6-2: Generic standards-Immunity standard for industrial environments
- IEC 61000-6-4:2018 Electromagnetic compatibility (EMC) Part 6-4: Generic standards-Emission standard for industrial environments