

The numbering for system module ID shall be the same as the module numbering printed on the side of the system cabinet. The number from the top to the bottom of the system cabinet shall be in the sequence of PM0 to PM7. The terminal resistance switch for module PM7 is set on the right. Terminal resistance switches for the other modules are set on the left. The terminal resistance switch for the power module of the display is set on the right.

When several SVG modules are connected in parallel sharing the same display, please make sure that the module IDs are not repeated. Besides, please make sure that the terminal resistance DIP switch of the SVG module that locates at the farthest from the display is set to the right.

- Each module has an individual ID.
- Module quantity and compensation capacity are correct.
- Parallel communication terminals are connected properly.
- Display communication ports are connected properly.
- The CT signal cables are well connected.
- Front door of the cabinet is closed.

4.2 Start-up Procedures

1. Switch on the main input breaker.
2. The internal auxiliary power supply of the modules will be started, and the fans will start working. Please make sure the yellow LED indicator in front of the module illuminates. After that, the display will show the start-up interface and communicate with the modules to read the system messages and check if there is any fault.
3. Close the front door.
4. Set the system into the operating mode. Please refer to **Chapter 5: Display and Settings** for the detailed display settings.
4. Press and hold the ON/ OFF button on the display. And press “Yes” when the “Start-up?” window pops up. The system will be starting up.
5. When the system starts up and works properly, the green LED indicator of HMI and Power modules will be ON.