

| Item | Description                                                                                    |
|------|------------------------------------------------------------------------------------------------|
| 10   | Shows the operating status of the device, status including Standby, Run, and locked.           |
| 11   | Displays the device wiring type, including 3P3W and 3P4W.                                      |
| 12   | Displays the device type, including compensator and harmonic source.                           |
| 13   | Power module quantity. The number of power module that builds a connection with the HMI.       |
| 14   | The load icon. Click to display detailed information regarding load measurement.               |
| 15   | The compensator icon. Click to display detailed information regarding compensator measurement. |
| 16   | The grid icon. Click to display detailed information regarding grid measurement.               |
| 17   | Page name.                                                                                     |