

## PLANT SYSTEMS

### 3/4.7.9 SNUBBERS

#### LIMITING CONDITION FOR OPERATION

---

3.7.9 All snubbers shall be OPERABLE.

APPLICABILITY: MODES 1, 2, 3 and 4. (MODES 5 and 6 for snubbers located on systems required OPERABLE in those MODES).

#### ACTION:

With one or more snubbers inoperable, within 72 hours, replace or restore the inoperable snubber(s) to OPERABLE status and perform an engineering evaluation per Specification 4.7.9 on the supported component or declare the supported system inoperable and follow appropriate ACTION statement for that system.

#### SURVEILLANCE REQUIREMENTS

---

4.7.9 Each snubber shall be demonstrated OPERABLE by performance of the Snubber Testing Program for examination, testing and service life monitoring of snubbers.

Pages 3/4 7-25 through 3/4 7-27 have been deleted.