## **ADJUSTMENT**

Set Knobs: SENS - full counterclockwise.

DECAY - full clockwise.

Connect an oscilloscope to OUTPUT through a millivoltmeter.

Feed a signal, 1kHz sine -45dBm, to INPUT. Adjust VR-3 and VR-4 for the values shown below.







