LADY LUCK

341

WILLIAMS ELECTRONICS INC.
3401 No. California Ave.
Chicago 60618 Illinois

ALL INTERLOCK RELAYS ARE SHOWN IN LATCHED POSITION

RELAY COIL LOCATIONS			
Advance Re	19 G	Player Reset Re	7 G
Ball Index Re	12 G	Replay Re	2 G
Change Re	22 G	Reset Re	3 G
Coin Re	2 G	R. O. Re	18 G
Dealer Re	19 G	Score Reset Re	3 G
Delay Re	13 G	Target Re	18 G
Eject Re	13 G	Tilt Re	10 G
Extra Ball Re	17 G	2nd Coin Re (Latch)	4 G
Game Over Re	12 G	2nd Coin Re (Trip)	4 G
Gate Re	23 G	10¢ Re	2 G
Lock Re	3 G	25¢ Re	1 G
No. 1 Joker Re	18 G	1 Pt. Re	20 G
No. 2 Joker Re	18 G	10 Pt Re	20 G
No. 1 Re	15 G	100 Pt Re	19 G
No. 2 Re	15 G	20 Re	15 G
No. 8 Re	16 G	1 Bumper Re	22 G
No. 9 Re	16 G	2 Bumper Re	23 G
Outhole Re	2 G	3 Bumper Re	23-G
Player Bust Re	15 G		
Player Re (2)	12 G		

MISCELLANEOUS COIL LOCATIONS	
Advance Unit	19 G
Ball Count Reset	4 G
Ball Count S.U.	9 G
Ball Release	12 G
Card Drum Unit (4)	8 G To 9 G
Coin Lockout	9 G
Eject Coil	7 G
Jet Bumpers (4)	5 G
Knocker	4 G
Large Bell	24 G
L. & R. Flippers	24 G
L. & R. Kickers	24 G
No Match S.U.	23 G
Playmeter	3 G
Relay Bank Reset	1 G
Replay S.U.	9 G
Replay Unit Reset	3 G
Score Drum Units (8)	7 G To 8 G

ABBREVIATIONS USED

Adj.—Adjustment	Imp.—Impulse	Pos.—Position
Amp.—Ampere	Ind.—Index	Re—Relay
Br.—Break	Ins.—Insert	R.P.—Replay
Bot.—Bottom	Lib.—Liberal	R.—Right
Cent.—Center	L—Left	R.O.—Roll Over
C.—Close	M-B—Make-Break	Sw.—Switch
Cons.—Conservative	No.—Number	Sws.—Switches
D.U.—Drum Unit	O.—Open	S.U.—Step Unit
E.O.S.—End of Stroke	P.F.—Playfield	V.—Volt
G.O.—Game Over	Pt.—Point	

WIRE COLOR CODE

R—Red	G—Green	O—Orange
Blu—Blue	W—White	B—Black
Y—Yellow	Br—Brown	J—Jumper

EXAMPLE:—W-R INDICATES WHITE WIRE WITH A RED TRACER.

SWITCH SYMBOL

⊣⊢	NORMALLY OPEN SWITCH CLOSED WHEN ENERGIZED.
⊣/⊢	NORMALLY CLOSED SWITCH OPEN WHEN ENERGIZED.
⊕	SWITCH CONTAINED WITHIN A CIRCLE INDICATES OPERATION BY A MOTOR CAM.
⊣/⊢	MAKE—BREAK SWITCH