

AMM - Hydraulic Pump Maintenance

1. General Description

This section describes the hydraulic pump system installed on the aircraft. The system provides pressure to flight control actuators and landing gear.

2. Removal Procedure

Depressurize the hydraulic system. Disconnect electrical connectors. Remove mounting bolts. Carefully extract the pump from the housing.

3. Installation Procedure

Position the pump. Install mounting bolts with torque specification. Reconnect electrical connectors. Perform leak test and operational check.

4. Safety Precautions

Ensure aircraft is powered down. Wear protective equipment. Follow lockout-tagout procedures.