

Production Process for HPC/HMI code

Nyle Systems Control Group

September 22, 2026

Abstract

This procedure configures a new stock HMI with the current HPC interface software. The provided USB provisioning media contains the application, required dependencies, and automated installer. No internet connection, additional hardware, or manual file copying is required.

1 Turn on the HMI

Providing power to the HMI should start the HMI. When it is fully loaded, you will see a desktop. The HMI may take approximately 30 seconds to boot initially.

2 Insert the HPC HMI provisional media

Insert the HPC HMI provisional media into any of the available USB type A connectors. The USB stick will auto mount. Select open, then double click on the "stock-hmi" application.

The application will run, and may reboot in the process. When it is complete, you will see the HPC HMI Graphical user interface.

Remove your HPC HMI provisional media.

Creating Replacement HMI Provisioning Media

If your HPC HMI provisioning media is lost, damaged, or otherwise unusable, create a replacement USB drive as follows:

1. On your PC, go to:
[https://github.com/NyleWaterHeatingSystems/stock_hmi]
2. Select **Download ZIP**, then extract the downloaded ZIP file.
3. Open the extracted folder and navigate to the BOOKWORM directory.

4. Insert a blank USB drive and copy the *contents* of the **BOOKWORM** directory to the top level of the USB drive.
5. Safely eject the USB drive.

The USB drive is now ready to provision an HPC HMI.