Production Process for HPC/HMI code

Nyle Systems Control Group

November 3, 2026

Abstract

This procedure configures a new stock HMI with the current HPC interface software. The provided USB provisioning media contains the application, required dependencies, and automated installer. No internet connection, additional hardware, or manual file copying is required.

1 Turn on the HMI

Providing power to the HMI should start the HMI. When it is fully loaded, you will see a desktop. The HMI may take approximately 30 seconds to boot initially.

2 Insert the HPC HMI provisional media

Insert the HPC HMI provisional media into any of the available USB type A connectors. The USB stick will auto mount. Select open, then double tap on the "stock-hmi" application.

The application will run, and the HMI will reboot in the process. When it is complete, you will see the HPC HMI Graphical user interface.

Remove your HPC HMI provisional media.

Creating Replacement HMI Provisioning Media

If your HPC HMI provisioning media is lost, damaged, or otherwise unusable, create a replacement USB drive as follows:

1. insert and format your USB stick as **exfat**
2. On your PC, go to:
   [`https://github.com/NyleWaterHeatingSystems/stock_hmi`]
3. Select **Download ZIP**, then extract the downloaded ZIP file.
4. Open the extracted folder and navigate to the `BOOKWORM` directory.
5. copy *contents* of the `TRIXIE` directory to the top level of the USB drive.
6. Safely eject the USB drive.

The USB drive is now ready to provision an HPC HMI.

Maintaining The Stock_HMI repo

1. git clone the repo
2. cd stock_HMI
3. python3 stock-hmi.py –update
4. additional debian packages should be added to debs folder. installation will be automatic.
5. git status
6. add any updated sources git add .
7. git commit -m "update sources"
8. git push

The provissers will now have the most current sources to the HMI software