

FieldTalk™ modpoll

Read Me Notes

Revision 3.1, 2011-07-22

This Read Me file contains last-minute product information for the FieldTalk™ modpoll utility.

modpoll is a command line based Modbus master simulator and test utility. It is free software.

Files part of the package

```
README.pdf
These Read Me notes.

LICENSE-FREE, LICENSE-FREE.pdf
License containing the Terms & Conditions of use for this free software.

linux/modpoll
Linux x86 binary

qnx6/modpoll
QNX 6 x86 binary

solaris/sparc/modpoll
Solaris SPARC binary (version 2.4 only)

win32/modpoll.exe
Windows command line binary

src/modpoll.cpp
Source for illustration purposes. Requires FieldTalk Modbus Master C++ Library to compile.
```

Usage

```
Usage: modpoll [OPTIONS] SERIALPORT | HOST [WRITEVALUES...]
Arguments:
SERIALPORT
              Serial port when using Modbus ASCII or Modbus RTU protocol
              COM1, COM2 ...
                                           on Windows
              /dev/ttyS0, /dev/ttyS1 ...
                                           on Linux
              /dev/ser1, /dev/ser2 ...
                                            on ONX
              Host name or dotted IP address when using MODBUS/TCP protocol
HOST
General options:
             Modbus ASCII protocol
-m ascii
              Modbus RTU protocol (default if SERIALPORT contains /, \\ or COM)
-m rtu
             MODBUS/TCP protocol (default otherwise)
-m tcp
-m enc
             Encapsulated Modbus RTU over TCP
             Slave address (1-255 for serial, 0-255 for TCP, 1 is default)\n
-a #
-r #
              Start reference (1-65536, 1 is default)
              Number of values to poll (1-125, 1 is default)
-c #
```

```
-t 0
             Discrete output (coil) data type
-t 1
             Discrete input data type
-t 3
              16-bit input register data type
-t 3:hex
              16-bit input register data type with hex display
-t 3:int
              32-bit integer data type in input register table
-t 3:mod
              32-bit module 10000 data type in input register table
-t 3:float
              32-bit float data type in input register table
              16-bit output (holding) register data type (default)
-t 4
-t 4:hex
             16-bit output (holding) register data type with hex display
-t 4:int
              32-bit integer data type in output (holding) register table
-t 4:mod
              32-bit module 10000 type in output (holding) register table
-t 4:float
              32-bit float data type in output (holding) register table
-i
              Slave operates on big-endian 32-bit integers
-f
              Slave operates on big-endian 32-bit floats
-е
             Use Daniel/Enron single register 32-bit mode
-0
             First reference is 0 (PDU addressing) instead 1
-1
             Poll only once only, otherwise every poll rate interval
-1
             Poll rate in ms, (1000 is default)
-0 #
             Time-out in seconds (0.01 - 10.0, 1.0 s is default)
Options for MODBUS/TCP:
              TCP port number (502 is default)
-p #
Options for Modbus ASCII and Modbus RTU:
-b #
             Baudrate (e.g. 9600, 19200, ...) (19200 is default)
-d #
             Databits (7 or 8 for ASCII protocol, 8 for RTU)
-s #
             Stopbits (1 or 2, 1 is default)
-p none
             No parity
             Even parity (default)
-p even
-p odd
              Odd parity
-4 #
              RS-485 mode, RTS on while transmitting and another # ms after
```

Release history

Version 3.1 (2011-05-27)

Slave ID of 0 is supported for Modbus/TCP

Version 3.0 (2011-03-05)

- Write function added
- protocol is now auto-detected as RTU or TCP depending on value of first parameter
- -I pollDelay parameter added Added "--" separator before values are printed to make parsing of result easier

Version 2.10 (2010-08-26)

-c parameter now accepts a value of 125.

• Changed default start reference (-r) to 1

Version 2.9 (2010-01-29)

• Fixed lock-up issue on some Linux platforms which was introduced in 2.7.

Version 2.8 (2009-11-16)

• Default baudrate is now 19200 as per Modbus standard.

Version 2.7 (2009-06-04)

Corrected help and range check for -a parameter

Version 2.6 (2008-10-30)

• Added option -0 for PDU addressing and option -e for Enron/Daniel 32-bit mode.

Version 2.5 (2008-04-03)

- A return code of 1 is returned if operation was not successful otherwise 0
- -c parameter now accepts a value of 100.
- Added time-out command line parameter.
- Retry count is now 0 for serial protocols (was 2 before).

Version 2.4.0 (2006-10-20)

• Default parity changed to even as per Modbus standard.

Revision 1.17 (2005-06-07)

• Using the -i command line parameters returned an error message in ealier releases.

Version 2.2.1 / Revision 1.16 (2004-09-22)

• Using the -d and -s command line parameters returned an error message in earlier releases.

Version 2.2 / Revision 1.15 (2004-04-25)

- RTU over TCP protocol added, which is also known as encapsulated RTU.
- Recompiled against 2.2 release of libmbusmaster.

Version 2003-05-20

- Recompiled against 2.0 release of libmbusmaster.
- RTU/ASCII: Added RS-485 mode for Win32, QNX and Linux platforms.
- ASCII: Fixed casting bug which caused protocol error when transmitting FF.
- MODBUS/TCP: Time-out applies now also when connecting to a server, tolerate a zero address field in an exception reply, fixed auto-retry.

Version 1.2 (2002-11-19)

- Terminates in case of a closed TCP/IP connection.
- Some error messages changed.
- Changed command line options for holding and input registers. -t4 is now holding register, -t3 input register.
- Retry option is now working.
- --version paremeter introduced.
- Retries fixed.
- -p parameter for MODBUS/TCP introduced.
- Default parity changed to NONE.
- Based on FieldTalk v1.3.

Version 1.1 (2002-07-15)

- Reference index print-out for 32-bit values corrected.
- Based on updated FieldTalk library which fixed issue with time-out monitoring

Version 1.0 (2002-03-03)

First release

Copyright (c) 2002-2011 proconX Pty Ltd. All rights reserved.

Email: mail@modbusdriver.com [mailto:mail@modbusdriver.com]

Please refer to file LICENSE-FREE for license and distribution terms.

THIS SOFTWARE IS PROVIDED BY PROCONX AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PROCONX OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.