

Address allocation and lease renewal

Node

Coordinator

Lease table

REGISTER uid + boot_id

scan addr 1..253

addr + epoch + 30 s lease

ADDR_ASSIGN

LEASE_RENEW at half life

LEASE_ACK / reject stale boot

A reboot changes boot_id, invalidating old sessions, jobs and leases.