Table shows Microtest user interface versions 0,1,2 and 3 DDE command support.

DDE DLL V1.40 Functions	Ver 6_0_X Software Functions	Ver 6_1_X Software Functions	Ver 6_2_X Software Functions	Ver 6_3_X Software Functions
MT_ActionConstantLoad	✓	✓	✓	✓
MT_ActionMeasure	✓	✓	✓	✓
MT_ActionStop	✓	✓	✓	✓
MT_AutoZeroLoadCell			✓	✓
MT_Clear	✓	✓	✓	✓
MT_Connect	✓	✓	✓	✓
MT_Disconnect	✓	✓	✓	✓
MT_GetErrorStr			✓	✓
MT_GetErrorStr2			✓	✓
MT_GetExtension	✓	✓	✓	✓
MT_GetMinExtension				✓
MT_GetMaxExtension				✓
MT_GetForce	✓	✓	✓	✓
MT_GetTargetForce	✓	✓	✓	✓
MT_GetMaxForce				✓
MT_GetGain			✓	✓
MT_GetGotoAction			✓	✓
MT_GetGotoUnits			✓	✓
MT_GetMotorSpeed			✓	✓
MT_GetMotorSpeedIndex			✓	✓
MT_GetPosition	✓	✓	✓	✓
MT_GetSampleTime			✓	✓
MT_GetStatus			✓	✓
MT_GetStatusJawTop			✓	✓
MT_GetStatusJawBottom			✓	✓
MT_GetTemperatureA			✓	✓
MT_GetTemperatureB			✓	✓
MT_GetTemperatureHSA			✓	✓
MT_GetTemperatureHSB			✓	✓
MT_GetTime	✓	✓	✓	✓
MT_GotoAbsolutePosition,	✓	✓	✓	✓
MT_GotoExtension	✓	✓	✓	✓
MT_GotoLoad	✓	✓	✓	✓
MT_GotoSeconds	✓	✓	✓	✓
MT_GotoValue	✓	✓	✓	✓
MT_IsConnected	✓	✓	✓	✓
MT_IsMotorRunning	✓	✓	✓	✓
MT_IsZeroLoadCellRunning			✓	✓
MT_IsZeroing			✓	✓

MT_ModeTensile			✓	✓
MT_ModeCompressive			✓	✓
MT_MoveApart	✓	✓	✓	✓
MT_MoveTogether	✓	✓	✓	✓
MT_SetGain	✓	✓	✓	✓
MT_SetGotoAction	✓	✓	✓	✓
MT_SetGotoUnits	✓	✓	✓	✓
MT_SetMotorSpeed	✓	✓	✓	✓
MT_SetSampleTime	✓	✓	✓	✓
MT_SetTemperatureA			✓	✓
MT_SetTemperatureB			✓	✓
MT_StartMotor	✓	✓	✓	✓
MT_StopMotor	see notes (1)	see notes (1)	✓	✓
MT_StopAll	✓	✓	✓	✓
MT_TemperatureControLOff			✓	✓
MT_Version	✓	✓	✓	✓
MT_SaveFile				see notes (2)
MT_SaveLin				see notes (3)
MT_CopyGraph				✓

Notes:

(1) MT_StopAll command must be used to stop the motor with Version 1 software. The MT_StopMotor command transmits ‘stop_motor’, but version 1 software expects to receive ‘stop’.

(2) Issue with 64 bit DDE DLL / test application. Creates file, but file name is not correct.

(3) May not be currently supported in user interface.