



Removal of the Front Cabinet and Mechanism

Fig. 6

0

 $\widehat{\Xi}$

1. Remove the screws (G) (2×6) mm $\times3$. 2. Remove the front cabinet & mechanism

Removal of the Cassette Holder & Equalizer PC board. (Fig. 6) 1. Remove the screws (H) (1.4×3.5)mm×2. Graphic

How to Replace the Cassette Lid Spring (Fig.

- 1. Enter the cassette foot (A) into the groove of the case body.
- Enter the boss of the cassette foot into the cave. To plug the torque spring into the groove of the case body.
- 4. Enter the cassette foot (B) into the groove of the case body

- Firstable turn the tuning shaft of the variable capacitor counter clockwise, to the end.
- 3. Thire to in stalle pointer, inserted pointer by rib "A" to before pointer be installed setted as shown. on chassis, pointer
- start point. (Fig. 8

Dial Pointer

alexj. 281@gmail.com

Fig. 8

Dial Gear

Rib "A