

uFR NDEF Version 1.0

Windows link: https://www.d-logic.net/code/nfc-rfid-reader-sdk/ufr-ndef-examples-c_sharp.git MacOS link:

https:/www..d-logic.net/code/nfc-rfid-reader-sdk/ufr-ndef-examples-objective_c-gui.git




Table of contents

Read NDEF	4
Write phone number	5
Write SMS	6
Write URI	7
Write vCard	8
Write Bluetooth address	9
TOOLS	10
Revision history	11



Read NDEF

Click on 'ReaderOpen' button and then click 'Read' button ('READ NDEF RECORD' - MacOS or 'Read Card' - Windows)




Always check status in at bottom left corner, if your status is UFR_OK, everything is fine, otherwise it's not.



Write phone number


Simply type phone number and click button to store it into card or into reader (tag emulation mode).





Write SMS


Type message you want to store and phone number and then click button to store the message and number into card or into reader (tag emulation mode).





Write URI


To write URI, choose URI Identifier Code from dropdown list and then type your URI field. After you finish, click button to store URI to card or into reader (tag emulation mode).





Write vCard


Fill all data you want to store for vCard and click button to write it into card or into reader (tag emulation mode).






Write Bluetooth address

Type Bluetooth address (6 bytes hexadecimal) and click button to store it into card or into reader (tag emulation mode).





TOOLS



At 'TOOLS' page you will be able to initialize card for NDEF it it's not already initialized (for example, you can initialize MIFARE® CLASSIC 1K card, erase last or all NDEF records from card, start tag emulation mode which will allow you to store NDEF messages to reader, also if you want you can stop tag emulation mode and you can read card's UID.



Revision history

Date	Version	Comment
2019-05-08	1.0	Base document