

General Car Service & Warning Manual

Sample Training Document for Retrieval-Augmented Generation (RAG)

This is a fictional, general-purpose vehicle manual created as sample data for educational use. It is not an official MG manual and must not be used as a substitute for the owner's manual or professional automotive advice.

Table of Contents

1	Safety and General Driving Advice
2	Dashboard Warning Messages
3	Engine and Petrol System
4	Gasoline Particulate Filter (GPF)
5	Electric Vehicle System
6	Battery and Charging
7	Brakes, Tyres and Steering
8	Routine Maintenance
9	Troubleshooting Guide
10	Emergency Procedures

1. Safety and General Driving Advice

Before Driving

Check that doors, bonnet and tailgate are properly closed. Confirm that mirrors are adjusted, tyres appear properly inflated, and no warning lights remain illuminated after the normal system check.

Warning Light Priority

A red warning generally indicates a condition requiring immediate attention. An amber or yellow warning usually indicates a fault, service requirement or system limitation. Always read the accompanying message where available.

Safe Stopping

If a serious warning appears, reduce speed safely, avoid sudden steering or braking, and stop in a safe location when practical. Do not continue driving if the vehicle indicates a critical oil pressure, brake, overheating or high-voltage system fault.

2. Dashboard Warning Messages

Check Engine Warning

The engine management system has detected a fault. If the light remains steady, avoid harsh acceleration and arrange inspection soon. If the light flashes, reduce engine load immediately and stop safely if the condition continues.

Low Engine Oil Pressure

Low oil pressure may cause severe engine damage. Stop the engine as soon as it is safe to do so. Do not continue driving until the cause has been checked.

Engine Temperature High

The engine cooling temperature is too high. Reduce load, stop safely and allow the engine to cool. Do not open a hot cooling system cap.

Brake System Warning

A brake system fault, low brake fluid condition or parking brake issue may be present. If braking performance is reduced, stop driving and arrange professional assistance.

Tyre Pressure Warning

One or more tyres may be under-inflated. Reduce speed, avoid harsh manoeuvres and check tyre pressures when safe. Inspect for punctures or visible damage.

12-Volt Battery Charging Fault

The 12-volt charging system may not be operating correctly. Reduce unnecessary electrical load and arrange inspection as soon as possible.

3. Engine and Petrol System

Fuel System

Use the fuel grade recommended for the vehicle. Do not continue to drive repeatedly with extremely low fuel, as some vehicles rely on fuel for cooling or lubrication of components.

Misfire or Rough Running

If the engine runs roughly, loses power or misfires, reduce load and avoid high speed. A flashing engine warning may indicate a condition that could damage the emissions system.

Catalyst Protection

Persistent misfires, incorrect fuel or severe engine faults may damage the catalytic converter. Have the vehicle inspected promptly if an engine warning remains on.

4. Gasoline Particulate Filter (GPF)

Gasoline Particulate Filter Full

The Gasoline Particulate Filter Full warning indicates that the filter has accumulated a high level of particulate material and requires regeneration or inspection. When safe and permitted by traffic and road conditions, drive the vehicle at a steady speed with the engine at normal operating temperature to support regeneration. If the warning remains illuminated after a suitable drive, or if additional warnings or reduced performance occur, arrange inspection by an authorised repairer as soon as possible.

Important GPF Precautions

Do not ignore a persistent filter warning. Avoid repeatedly switching off the engine immediately after very short journeys if the vehicle is attempting a regeneration cycle. Do not perform high-speed driving solely to clear a warning; always obey speed limits and drive only when conditions are safe.

Severe Filter Condition

If the filter warning is accompanied by a flashing engine warning, severe power reduction or another critical message, stop driving when safe and contact qualified service support.

5. Electric Vehicle System

EV System Fault

An electric drive system warning indicates that a fault has been detected in the propulsion or high-voltage system. If performance is limited, drive cautiously to a safe location and follow the instructions displayed by the vehicle.

High-Voltage Warning

Do not touch orange high-voltage cables or attempt repairs to high-voltage components. High-voltage systems should only be inspected by trained technicians.

Reduced Power

Reduced power can occur because of low battery charge, high or low battery temperature, or a system fault. If power remains restricted after normal conditions return, arrange inspection.

6. Battery and Charging

Low State of Charge

Recharge the traction battery before the displayed range becomes critically low. Range is affected by speed, temperature, terrain, tyre pressure, heating and air-conditioning.

Charging Fault

If charging does not start, check that the connector is fully engaged and that the charging equipment is functioning. Stop using damaged cables or connectors and have them inspected.

Battery Temperature

Very hot or cold battery conditions may temporarily reduce charging speed or vehicle performance. Follow vehicle messages and allow the battery management system to control charging when necessary.

7. Brakes, Tyres and Steering

Brake Wear

A brake wear message indicates that brake pads may require inspection or replacement. Do not delay service if braking noise, vibration or reduced performance is present.

ABS Warning

If the ABS warning remains on, normal braking may still be available but anti-lock functionality may be unavailable. Drive cautiously and arrange inspection.

Power Steering Fault

Steering assistance may be reduced. The steering wheel may require greater effort. Reduce speed and arrange service if the warning persists.

Tyre Damage

Do not drive on a visibly damaged or severely under-inflated tyre. Stop safely and inspect the tyre before continuing.

8. Routine Maintenance

Weekly Checks

Check tyre condition, tyre pressure, exterior lights, washer fluid and for visible leaks. Investigate new noises or warning messages promptly.

Monthly Checks

Check engine oil level where applicable, coolant level according to the vehicle procedure, brake fluid condition, and 12-volt battery condition where accessible.

Service Intervals

Follow the manufacturer's recommended time and distance service intervals. Severe driving conditions, frequent short trips, towing or extreme temperatures may require more frequent maintenance.

Tyres

Maintain tyre pressures at the recommended values for the vehicle load. Incorrect pressure can affect handling, braking, tyre wear and driving range for electric vehicles.

9. Troubleshooting Guide

Vehicle Will Not Start

Check the key or start authorization, battery charge and displayed warning messages. For an EV, confirm that the vehicle is in the correct ready state. Do not repeatedly attempt to start a vehicle showing a serious system fault.

Vehicle Has Reduced Power

Check for warning messages. Reduced power may be caused by engine protection, battery temperature, low state of charge, emissions system faults or other system limitations.

Unusual Noise

A new knocking, grinding, scraping or high-pitched mechanical noise should be investigated. Stop driving if the noise is severe or accompanied by a warning light.

Warning Light Remains After Restart

Do not assume a persistent warning is harmless. Consult the vehicle manual or arrange professional diagnosis, especially for brake, oil pressure, temperature or high-voltage warnings.

10. Emergency Procedures

Stop Safely

Switch on hazard warning lights where appropriate, move to a safe location and keep clear of traffic. Follow local laws and emergency procedures.

Fire or Smoke

Stop the vehicle safely, evacuate occupants and move away from the vehicle. Contact emergency services. Do not attempt to repair a high-voltage battery or open sealed electrical components.

Breakdown Assistance

Provide the vehicle model, warning message, location and whether the vehicle is petrol, hybrid or electric. This information helps the assistance provider prepare appropriate equipment.