
## Command Reference: SetDiversionStationDelayTablesFromNetwork()

## Set diversion station delay table data from the network

## **StateMod Command**

Version 3.09.01, 2010-02-01

The SetDiversionStationDelayTablesFromNetwork () command sets delay table data in existing diversion stations using network information. A default delay table is used to assign 100% of the returns to the downstream node in the network. This command is often used to set a default before more specific delay table information is set with the SetDiversionStationDelayTablesFromRTN() command. The following dialog is used to edit the command and illustrates the syntax of the command.



SetDiversionStationDelayTablesFromNetwork() Command Editor

The command syntax is as follows:

 ${\tt SetDiversionStationDelayTablesFromNetwork\,(Parameter=Value,...)}$ 

## **Command Parameters**

Parameter	Description	Default
ID	A single diversion station identifier to match or a	None – must be specified.
	pattern using wildcards (e.g., 20*).	
DefaultTable	The default delay table to use when assigning the delay	None – must be specified.
	tables.	
IfNotFound	Used for error handling, one of the following:	Warn
	• Fail – generate a failure message if the ID is not matched	
	Ignore – ignore (don't add and don't generate a message) if the ID is not matched	
	Warn – generate a warning message if the ID is not matched	