
## Command Reference: FillWellStation()

## Fill well station data

## StateMod Command

Version 3.09.01, 2010-02-01

The FillWellStation() command fills missing data in existing well stations. The following dialog is used to edit the command and illustrates the syntax of the command.



FillWellStation() Command Editor

FillWellStation

The command syntax is as follows:

FillWellStation(Parameter=Value,...)

## **Command Parameters**

Parameter	Description	Default
ID	A single well station identifier to match or a pattern	None – must be specified.
	using wildcards (e.g., 20*).	_
Name	The name to be assigned for all matching well	If not specified, the original
	stations with missing name.	value will remain.
RiverNodeID	The river node identifier to be assigned for all	If not specified, the original
	matching well stations with missing river node	value will remain.
	identifier. Specify ID to assign to the well station	
	identifier.	
OnOff	The on/off switch value to be assigned for all	If not specified, the original
	matching well stations with missing switch, either 1	value will remain.
	for on or 0 for off.	
Capacity	The well station capacity to be assigned for all	If not specified, the original
	matching well stations with missing capacity, CFS.	value will remain.
DailyID	The daily identifier to be assigned for all matching	If not specified, the original
	well stations with missing daily identifier or use ID to	value will remain.
	use the station identifier.	
AdminNumShift	The administration number shift to be assigned to	If not specified, the original
	water rights for all matching well stations with	value will remain.
	missing value. See the "primary" flag in the	
	StateMod well station documentation.	
DiversionID	For all matching well stations, the diversion station	If not specified, the original
	identifier associated with the well station. Typically,	value will remain.
	where well water supplements surface supply, one	
	well station is assigned to the diversion station.	
	Specify ID to assign to the well station identifier.	
DemandType	The demand type to be assigned for all matching well	If not specified, the original
	stations with missing demand type (see StateMod	value will remain.
T 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	documentation).	70 10 1 1 1 1
IrrigatedAcres	The irrigated acres to be assigned for all matching	If not specified, the original
	well stations with missing irrigated acres.	value will remain.
UseType	The use type to be assigned for all matching well	If not specified, the original
	stations with missing user type (see StateMod	value will remain.
DemandSource	documentation).	70
DemandSource	The demand source to be assigned for all matching	If not specified, the original
	well stations with missing demand source (see	value will remain.
Eff Annual	StateMod documentation).	If not an elficit the elicinat
EffAnnual	The annual efficiency (percent, 0 - 100) to be	If not specified, the original
	assigned for all matching well stations with missing	value will remain.
	annual efficiency (see StateMod documentation).	
	Monthly efficiencies will be set to the same value (but	
EffMonthly	not used).  The monthly efficiencies (percent 0, 100) to be	If not specified the emissions!
ELLIMOITCHLY	The monthly efficiencies (percent, 0 – 100) to be	If not specified, the original
	assigned for all matching well stations with missing	value will remain.
	values, specified as 12 comma-separated values,	
	January to December. The annual efficiency will be	
	set to the average value. The order of the values in	
	the output file will be according to the output year	

Parameter	Description	Default
	type set by setOutputYearType(), or calendar	
	by default.	
Returns	The return flows to be assigned for all matching well	If not specified, the original
	stations with missing returns. Specify as	value will remain.
	StationID, Percent, DelayTableID;	
	StationID, Percent, DelayTableID; etc.	
Depletions	The depletions to be assigned for all matching well	If not specified, the original
	stations with missing depletions. Specify as	value will remain.
	<pre>StationID, Percent, DelayTableID;</pre>	
	StationID, Percent, DelayTableID; etc.	
IfNotFound	Used for error handling, one of the following:	Warn
	• Fail – generate a failure message if the ID is not	
	matched	
	• Ignore – ignore (don't add and don't generate a	
	message) if the ID is not matched	
	• Warn – generate a warning message if the ID is not matched	

FillWellStation()	Command )
-------------------	-----------

This page is intentionally blank.