Command Reference: ReadPropertiesFromFile()

Read one or more time series processor properties from a file

Version 10.12.00, 2012-08-02

The ReadPropertiesToFile() command reads the values of one or more time series processor properties from a file. The corresponding WritePropertiesToFile() command can be used to write properties to a file. Processor properties include global defaults such as InputStart, InputEnd, OutputStart, OutputEnd, OutputYearType, WorkingDir, and also user-defined properties set with the SetProperty() command. Internally, properties have a name and a value, which is of a certain type (string, integer, date/time, etc.). Examples of using the command include:

- creating tests to verify that properties are being set
- passing information from another program, such as a Python script, to TSTool
- reading persistent information from a previous use, such as the date/time that data were last downloaded from a web service

A number of property formats are supported as listed in the following table.

Property File Formats

Format	Description		
NameValue	Simple format, all properties handled as text:		
	PropertyName=PropertyValue		
	PropertyName="Property value, quoted if necessary"		
NameTypeValue	Same as NameValue format, with non-primitive objects treated as simple		
	constructors:		
	PropertyName=PropertyValue DateTimeProperty=DateTime("2010-10-01 12:30")		
NameTypeValue	Similar to the NameTypeValue format, however, objects are represented		
Python	using "Pythonic" notation, to allow the file to be used directly by Python		
	scripts:		
	PropertyName="PropertyValue"		
	DateTimeProperty=DateTime(2010,10,1,12,30)		

The format of the file currently is not required when reading the file because the command detects the format for each property and creates an appropriate object type. If this becomes an issue, the command may be enhanced to add a parameter to specify the format (similar to the WritePropertiesToFile() command).

The following dialog is used to edit this command and illustrates the syntax of the command.



ReadPropertiesFromFile() Command Editor

ReadPropertiesFromFile

The command syntax is as follows:

ReadPropertiesFromFile(Parameter=Value,...)

Command Parameters

Parameter	Description	Default
InputFile	The property file to read, as an absolute path or	None – must be specified.
	relative to the command file.	
IncludeProperty	The names of properties to read, separated by	If not specified, all
	commas.	processor properties will
		be written.