Quick Start Guide

OpenEVSE

Guides

Visit our online guide site for assembly instructions or to learn more advanced topics.
Web: guides.openevse.com

Electrical

This OpenEVSE controller can be setup charge from 6A up to 80A. Set current based on the lowest continuous rating of your equipment, cables and circuit.

Electric vehicle charging is considered a continuous load. In the US the National Electric Code requires a 20% de-rate.

100A circuit - 80A Maximum
80A circuit - 64A Maximum
60A circuit - 48A Maximum
50A circuit - 40A Maximum
40A circuit - 32A Maximum
30A circuit - 24A Maximum

Color Display

Visualize the status of your station from a distance with on board color LEDs

- Ready - Green
- Connected -Yellow
- Charging - Blue
- Error - Red
- Sleeping - Purple

Connect WiFi

Connect to your WiFi network with a phone, tablet, or computer. Visit our online guide for more detail.

- Network: OpenEVSE_*xxxx*
  * note the unique 4 digits
- Password: openevse
- Open web browser enter openevse-xxxx.local or 192.168.4.1
- select your network
- enter your network password
- reconnect to openevse-xxxx.local

Support

Contact us with any questions

Web: support.openevse.com
E-mail: support@openevse.com
Phone: (877) 967-3638

Returns

Return your product? Please contact support and return products to:

OpenEVSE Store
6711 Sugar and Wine Road
Monroe, NC 28110

Copyright 2025 – OpenEVSE LLC