

140
120
100
80
60
40
20
0
-20
-40
-60
-80
-100

Scale is to calibrate actual printed dimension. Check both X and Y. Measure between tick 0 and last tick

-160 -140 -120 -100 -80 -60 -40 -20 0 20 40 60 80 100 120 140 160 180 200 220 240

