



OPEN PROTOCOL FOR ELECTRIC NETWORKS

Document Name
Last update
Version

OpenWebNet_L4686SDK_WHO-6_vdes_v1_0_0.doc
11 / 02 / 2009
1.0.0

Modification History

Version	Date	Author
1.0.0	11/02/2009	Bticino S.p.A.
First Release		



Index

WHAT Table:	3
WHERE Table:	3
1. Sending OpenWebNet frames.....	4
1.1. Camera ON	4
1.2. Raiser Camera ON	4
1.3. Camera OFF	4
1.4. Switch ON / OFF Stair Light	5
1.5. Open Lock.....	5
1.6. Open Raiser Lock.....	5
1.7. Camera Cycling.....	6
1.8. Raiser Camera Cycling	6
2. Receiving OpenWebNet Messages	7
2.1. Camera ON	7
2.2. Camera OFF	7
2.3. Indoor Panel receiving call.....	7
2.4. Broadcast receiving call	7
2.5. Stair Light ON / OFF	8
2.6. Open Lock.....	8
2.7. Open Raiser Lock.....	8
2.8. Open Lock with EU in conversation.....	8

Video door entry System (WHO = 6)

WHAT Table:

0	Camera ON
6	Entering call
9	Camera OFF
10	Open Lock
11	Switch OFF Stair Light
12	Switch ON Stair Light
18	Camera Cycling
22	Open Lock with EU in conversation

WHERE Table:

0	Apartment 0
1	Apartment 1
...	...
3999	Apartment 3999
4000	Control Panel / External Site / Actuator 0
4001	Control Panel / External Site / Actuator 2
...	...
4095	Control Panel / External Site / Actuator 95

1. Sending OpenWebNet frames

1.1. Camera ON

Flow	Frame OpenWebNet	Notess
Client → L4686SDK	*6*0*where##	where = [4000 - 4095]
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.2. Raiser Camera ON

Flow	Frame OpenWebNet	Notess
Client → L4686SDK	*6*0*where#2##	where = [4000 - 4095]
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.3. Camera OFF

Flow	Frame OpenWebNet	Notess
Client → L4686SDK	*6*9##	
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.4. Switch ON / OFF Stair Light

Flow	Frame OpenWebNet	Notes
Client → L4686SDK	*6*what*where##	where = L4686SDK address what: 11 = switch OFF 12 = switch ON
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.5. Open Lock

Flow	Frame OpenWebNet	Notess
Client → L4686SDK	*6*10*where##	where = [4000 - 4095]
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.6. Open Raiser Lock

Flow	Frame OpenWebNet	Notess
Client → L4686SDK	*6*10*where#2##	where = [4000 - 4095]
L4686SDK ← Client	***1## ***0## ***x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.7. Camera Cycling

Flow	Frame OpenWebNet	Notes
Client → L4686SDK	*6*18*where##	ATTENTION: This frame has to be send only after an ON CAMERA frame where = [4000 - 4095]
L4686SDK ← Client	##*1## ##*0## ##*x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

1.8. Raiser Camera Cycling

Flow	Frame OpenWebNet	Notes
Client → L4686SDK	*6*18*where#2##	ATTENTION: This frame has to be send only after an ON CAMERA frame where = [4000 - 4095]
L4686SDK ← Client	##*1## ##*0## ##*x##	ACK - if frame is sent on the SCS BUS NACK - if frame is not sent on the SCS BUS NACK x - if frame is not sent, x is type error

2. Receiving OpenWebNet Messages

2.1. Camera ON

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*0*where##	where = [4000 - 4095]

2.2. Camera OFF

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*9##	

2.3. Indoor Panel receiving call

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*6*where##	where : [0 - 3999]

2.4. Broadcast receiving call

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*6*4100##	

2.5. Stair Light ON / OFF

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*what*where##	where = L4686SDK address what: 11 = switch OFF 12 = switch ON

2.6. Open Lock

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*10*where##	where = [4000 - 4095]

2.7. Open Raiser Lock

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*10*where#2##	where = [4000 - 4095]

2.8. Open Lock with EU in conversation

Receiving	Frame OpenWebNet	Notes
L4686SDK ← Client	*6*22*where##	where = [4000 - 4095]