



DJI Osmo Pocket 4 Release Notes

Date:	2026.09.08
Firmware Version:	v01.03.14.04
DJI Mimo App iOS:	v2.11.8
DJI Mimo App Android:	v2.11.8
Osmo FrameTap:	v01.02.08.02

What's New

- Added HDR 10-bit color mode, supporting 10-bit high dynamic range video capture. Play back footage on a device that supports high dynamic range display for the best viewing experience.
- Added support for HDR Enhancement in Photo mode. Play back footage on a device that supports high dynamic range display for the best viewing experience.
- Added a D-Log 10-bit color mode for slow motion.
- Added joystick support for 45° diagonal gimbal movement.
- Optimized the interaction experience and image quality in certain scenarios.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.
Contact DJI Support if the update fails again.
2. Accessory updates:
 - a. Once connected to the camera, the battery handle and fill light will be updated together with the camera firmware. A prompt will appear on the camera screen when the update is complete. Do not remove the accessories until the update completes.
 - b. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4. Disconnect Osmo Pocket 4 before updating.
3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
DJI Mic 3 Transmitter: v02.00.11.01 or above
DJI Mic Mini Transmitter: v01.01.00.56 or above
DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4 Release Notes

Date:	2026.08.04
Firmware Version:	v01.03.10.05
DJI Mimo App iOS:	v2.10.12
DJI Mimo App Android:	v2.10.12
Osmo FrameTap:	v01.02.08.02

What's New

- Added Camera Cloud Service, supporting uploading camera files to cloud storage. The supported cloud services vary depending on country/region and mobile device type. Currently supported services include Google Drive, OneDrive, and the user's own NAS. Supported services may be adjusted in future updates.
- Added support for Frame Tracking. The camera automatically matches and selects an ActiveTrack subject. When the subject frame turns yellow, press the joystick once to start tracking while maintaining the current composition.
- Added support for automatic brightness and color temperature adjustment for the fill light. When enabled, brightness and color temperature automatically adapt to the current scene without frequent manual adjustments.
- Added a press-and-hold setting for the Custom Button. Press and hold the Custom Button to zoom out or open the custom settings menu.
- Added a virtual custom button in portrait mode, supporting single press, double press, triple press, and press and hold action, which can be customized in the settings.
- Added support for the Osmo FrameTap remote controller, allowing free adjustment of gimbal direction and composition for remote recording.
- Added mode memory to Smart Gimbal Mode. After restarting the camera, it will stay in the last selected smart gimbal mode.
- Added zoom to Smart Gimbal Mode. During tracking, push the joystick, or press, double press, or press and hold the button to zoom.
- Optimized the interaction experience and image quality in certain scenarios.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. Accessory updates:
 - a. Once connected to the camera, the battery handle and fill light will be updated together with the camera firmware. A prompt will appear on the camera screen when the update is complete. Do not remove the accessories until the update completes.
 - b. Connect Osmo FrameTap remote controller to DJI Mimo to update its firmware. The remote controller does not support simultaneous connections to a mobile device and Osmo Pocket 4.

<https://www.dji.com/osmo-pocket-4>



DJI Osmo Pocket 4 Release Notes

Disconnect Osmo Pocket 4 before updating.

3. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:

DJI Mic Mini 2 Transmitter: v02.03.17.00 or above

DJI Mic 3 Transmitter: v02.00.10.01 or above

DJI Mic Mini Transmitter: v01.01.00.56 or above

DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4 Release Notes

Date:	2026.06.30
Firmware Version:	v01.02.07.06
DJI Mimo App iOS:	v2.10.2
DJI Mimo App Android:	v2.10.2

What's New

- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
 - DJI Mic 3 Transmitter: v02.00.10.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4 Release Notes

Date:	2026.06.09
Firmware Version:	v01.02.07.05
DJI Mimo App iOS:	v2.9.4
DJI Mimo App Android:	v2.9.5

What's New

- Added support for Direct Transfer to Huawei Devices. You can select footage directly on the camera playback screen and transfer it to Huawei devices with one tap. Ensure the mobile device supports HarmonyOS 6.1 or later, and enable Everyone in Huawei Share before sharing for the first time.
- Added support for linking the DJI Mic Mini 2 transmitter to Osmo Pocket 4 for audio recording.
- Added support to set the Press & Hold Joystick function to Lock Gimbal or Lock Camera Direction in system settings. When Lock Gimbal is selected, the gimbal can move with your hand.
- Press and hold the Zoom Button to continuously zoom in.
- Optimized gimbal responsiveness in Photo mode for smoother tracking, making it easier to frame and capture the moment without affecting gimbal stabilization.
- Improved image quality in certain scenarios.
- Fixed some known issues.
-

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
 - DJI Mic Mini 2 Transmitter: v02.03.17.00 or above
 - DJI Mic 3 Transmitter: v02.00.10.01 or above
 - DJI Mic Mini Transmitter: v01.01.00.56 or above
 - DJI Mic 2 Transmitter: v04.05.01.11 or above



DJI Osmo Pocket 4 Release Notes

Date:	2026.04.16
Firmware Version:	v01.01.32.02
DJI Mimo App iOS:	v2.8.1
DJI Mimo App Android:	v2.8.1

What's New

- Added support for burst shooting to SuperPhoto mode. Quickly press the shutter/record button for multiple times for bursting shooting, allowing to capture highlight moments easily. After shooting, wait until saving is complete.
- Added support for Live Photos in Standard Photo mode. When enabled, you can capture live photos in the camera and quickly export them to your mobile device using DJI Mimo.
- Added support for automatic Low-Light Image Enhancement in Video mode (only available for 30 fps and below). When enabled, the camera will automatically detect low-light environment and switch to low-light mode, helping to improve image brightness and reduce noise. This feature is enabled by default and can be disabled in shooting settings.
- Improved zoom smoothness for more natural zooming effects when recording videos.
- Improved the image quality in Video mode for backlit scenes.
- Added a second page settings to the Control Center. Swipe down to open Control Center, then swipe left to view it.
- Optimized the interactive interface layout for improved user experience.
- Fixed some known issues.

Notes:

1. If the update fails, follow the steps for troubleshooting.
 - a. Restart Osmo Pocket 4 and DJI Mimo.
 - b. Enable Wi-Fi and Bluetooth on the mobile device.
 - c. Connect Osmo Pocket 4 to DJI Mimo and try the update again.Contact DJI Support if the update fails again.
2. When using with DJI Mic series, make sure the transmitter is updated to the latest compatible version:
DJI Mic 3 Transmitter: v02.00.10.01 or above
DJI Mic Mini Transmitter: v01.01.00.56 or above
DJI Mic 2 Transmitter: v04.05.01.11 or above