```
There are two types of maintenance panel codes:
                                                      progress codes and
error codes. Progress codes are placed in the Maintenance Panel at various
stages of initialization. Error codes are traps which freeze or blink the
error number in the maintenance panel. They are all fatal errors.
0000-0499 boot-time diagnostics
0500-0699 IOP code
0700-0899 Pilot microcode
0900-0999 Pilot
1000-6999 tech-rep diagnostics
7000-8887 Star
8888-8888 MP lamp test
9000-9999 Lisp
0096 Insufficient real memory (<1MByte) for lisp
0200-0299 Booting phase 2 (Initial microcode)
0200 normal booting phase 2
0201 CP error in reading from boot device
0202 null Mesa germ installed in physical volume
0203 broken rigid disk boot chain (possibly intermitant)
0204 Illegal IOP port command
0205 CP Trap (CS parity or double-bit memory error)
0206 null diagnostic microcode in physical volume
0207 null Pilot/Mesa emulator microcode in physical volume
         null Mesa germ installed in physical volume
0500-0502 Domino progress codes
0500
          StartDomino
                           Domino has started
0501
          InitReadTOD
                           Domino starting to read the TOD clock
0502
          InitReadTODdone
                               Reading of TOD clock completed
             (next MP number from Lisp)
0505-0599 Domino error codes
0505
          CSParity
                        CS parity error detected
0506
          BurdockCPDisabled
                                 Burdock attempted to use EtherKludge
0507
          CPBurdockDisabled
                                 CP attempted to use EtherKludge
                     An IOP break with no IOP kernel
0508
          IOPBreak
0509
          IllegalIOPIntr
                              Illegal IOP interrupt
0510
          BadMapEntry
                           Incorrect vm Map entry in IOP access.
0511
          NoCPDmaComplete
                               CP Dma operation failed to complete
0512
         NoCPDmaChannel
                              CP Dma channel not specified
0513
          ReadCPPortDead
                              CP not responding to Read CPPort
0514
         WriteCPPortDead
                              CP not responding to Write CPPort
                             A task's stack has overflowed
0520
          StackOverflow
0565
          InvToneCmd
                          Invalid keyboard tone generator comnd
0570
                          Invalid cmd value in Processor CSB
          InvProcCmd
0571
                         Unimplemented cmd in Processor CSB
          UnImplCmd
0572
                           The Time-Of-Day could not be set
          SetTODError
                          LSEP Control CSB overrun
0576
         LSEPCtlOVR
                              Invalid floppy IOCB command
0580
         NoValidCommand
                               Unimplemented floppy IOCB cmd
0581
          UnImplFloppyCmd
0582
          InvalidEscapeCmd
                                Invalid Escape floppy cmd
                            Floppy track register is not correct
0583
          CommandTrack
0584
          TrackToBig
                          Floppy track number is too large
0585
          BadDmaChannel
                             Couldn't program Floppy Dma
0586
          NoDmaEndCount1
                              External Dma End Count not set
         NoDmaEndCount2
                              Internal Dma End Count not
0587
set e8(0,4704)(1,9760)
9000-9299 DLion lisp microcode error detected
9001 Control store parity error
9004 Attempt to reference virtual address >22 bits
```

```
9005 double bit memory error or non-existant memory reference
9001
          CSParErr Control store parity error
9002
          StackErr hardware stack overflow
9003
          IBEmptyErr instruction fetch unit empty error
          VirtAddrErr Attempt to reference virtual address >22 bits
9004
          EmuMemErr double bit memory error or non-existant memory
9005
9013
          NegPcError
                          inconsistent PC at FnCall
9014
          applyUfn
                        arg to apply not integer
9016
          notFreeTrap
                           stack allocation error
9051
          BadUfnTable
9120
                       opcode no such register
          MiscErr
                       opcode bad 2nd byte
9121
         MiscErr
9136
          CycleMask
                         bad caller
9129
         M1Loc microcode error
9130
         M2Loc microcode error
9131
          M3Loc microcode error
9048
          ReFOvr page fault under page fault
9049
          Ghost context switch
9127
          PcNegError
                          inconsistent PC at Punt
9300-9399 Lisp error calling \MP.ERROR
9301
          \MP.NORPT
                     "No space for Real Page Table"
9302
          \MP.INVALIDVMEM
          \MP.IOCBPAGE "No place for IOCB page at startup"
9303
9304
                  "Map out of bounds"
          \MP.MOB
9305
          \MP.INVALIDADDR
9306
          \MP.INVALIDVP
          MP.CHAIN.UNAVAIL "Unavailable page on real page chain"
9307
          \MP.SELECTLOOP "Loop in \SELECTREALPAGE"
9308
9309
          \MP.NEWPAGE "Attempt to allocate already existing page"
          \MP.NEWMAPPAGE "\DONEWPAGE failed to allocate new map page"
9310
9311
          \MP.BADLOCKED
                        "Locked page occupies a file page needed to lock
another"
9312
          \MP.CLOCK0
                     "Arg to CLOCKO not an integer box"
9313
          \MP.RESIDENT "Fault on resident page"
          MP.STACKFAULT "Fault on stack"
9314
9315
                          "Vmem inconsistent at startup"
          \MP.INVALIDVMEM
9400-9899 unassigned
9900-9999 Attempt to call Raid or Alto O.S. (BCPL Subr)
9900
          \uCodeCheck
9901
          was\StackOverflow
9902
          \NWWInterrupt
9903
          was\PageFault NIL
9904
          \StatsOverflow
9905
          NOOPSUBR
9906
          \BACKGROUNDSUBR
9907
          \CHECKBCPLPASSWORD
9908
          DISKPARTITION NIL
9909
          DSPBOUT (CHARCODE)
9910
          \DSPRATE (PARM)
9911
          \GATHERSTATS (FID)
9912
          \GETPACKETBUFFER NIL
9913
          \LISPFINISH
9914
          \MOREVMEMFILE (FILEPAGE)
9915
          RAID (MESS1 MESS2 FLG)
9916
          \READRAWPBI NIL
9917
          \WRITERAWPBI (PBI)
9918
          SETSCREENCOLOR (FLG)
          SHOWDISPLAY (BASE RASTERWIDTH)
9919
9920
          \PUPLEVEL1STATE (FLG)
9921
          \WRITESTATS (TYPE X1 X2 X3 X4 X5 X6 X7 X8 X9 X10)
9922
          \CONTEXTSWITCH
9923
          \COPYSYS0SUBR (FID)
```