Whirlpool

Use and care guide

Top-load washer · Model WTW5000DW

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using the washer. Do not wash items that have been cleaned in or spotted with gasoline or other flammable substances. Keep children away from the washer while it is running.

LOADING

- Load dry, unfolded items loosely around the wash plate.
- Do not wrap large items around the center.
- Mix large and small items for a balanced load.

DETERGENT

Use only HE (high efficiency) detergent. Add detergent to the dispenser before adding the load. Too much detergent can leave residue and cause odors.

CYCLE GUIDE

- Regular / Normal: cottons, linens and mixed loads.
- Heavy Duty: sturdy fabrics and heavily soiled items.
- Delicates: lightly soiled items that need gentle care.
- Rinse & Spin: rinse without a full wash.

NOISES YOU MAY HEAR

Clicking or humming during fill and spin is normal. A loud grinding or banging noise during spin can mean an unbalanced load or a problem with the drive system. Stop the washer, rebalance the load and try again. If the noise continues, call for service.

CARE

Leave the lid open after use so the basket can dry. Clean the basket monthly with an affresh-type cleaner or a cleaning cycle.

BEFORE YOU CALL FOR SERVICE

Have your model and serial number ready. They are printed on the label under the lid.