

## Switch 1.6

```
enable
conf t
interface f0/1
switchport mode trunk
switchport trunk allowed vlan 40
no shutdown
exit

interface range f0/3 - 48
switchport mode access
switchport access vlan 40
no shutdown
exit
```



## Switch 2.5

```
enable
conf t
interface f0/1
no shutdown
exit

interface f0/2
no shutdown
exit

interface f0/3
no shutdown
exit
exit
wr
```

## Switch 1.5

```
enable
conf t
interface f0/1
switchport trunk encapsulation dot1Q
```

```
switchport mode trunk
switchport trunk allowed vlan 40
no shutdown
exit
```

```
interface range f0/3 - 48
switchport mode access
switchport access vlan 40
no shutdown
exit
exit
wr
```

## Switch 1.4

### 1 IP

```
enable
interface fa0/1
switchport trunk encapsulation dot1Q
exit
switchport mode trunk
switchport trunk allowed vlan 10,20
no shutdown
exit

interface range fa0/2 - 16 (15membres pour une marge de 3)
switchport mode access
switchport access vlan 10
no shutdown
exit

interface range fa0/17 - 48
switchport mode access
switchport access vlan 20
no shutdown
exit
wr (write memory pour save la config)
```

## Switch 2.6

```
enable
conf t

interface f0/1
switchport mode trunk
switchport trunk allowed vlan 30,40
no shutdown
exit

interface range f0/4 - 25
switchport mode access
switchport access vlan 30
no shutdown
exit

interface range f0/26 - 48
switchport mode access
switchport access vlan 40
no shutdown
exit
exit
wr
```

## Switch 2.4

```
enable
interface fa0/1
switchport trunk encapsulation dot1Q

switchport mode trunk
switchport trunk allowed vlan 50,60
no shutdown
exit

interface range fa0/2 - 16
switchport mode access
switchport access vlan 50
no shutdown
exit

interface range fa0/17 - 48
switchport mode access
```

```
switchport access vlan 60  
no shutdown  
exit  
exit  
wr (write memory pour save la config)
```