

MOTOCRAFT ZX-9000 SERVICE MANUAL

Revision 3 - Internal use only

ENGINE SPECIFICATIONS

Model:	Motocraft ZX-9000
Type:	Single-cylinder, liquid-cooled, 4-stroke, DOHC
Displacement:	742 cc
Bore x Stroke:	97.0 x 100.4 mm
Compression ratio:	11.3:1
Spark plug gap:	1.23 mm
Idle speed:	1450 +/- 100 r/min
Valve clearance (cold):	
Intake:	0.14-0.18 mm
Exhaust:	0.23-0.27 mm

ENGINE FLUIDS

Engine oil capacity:	
Without filter:	3.47 L
With filter:	3.61 L
Coolant capacity:	1.83 L

ELECTRICAL

Battery:	YTX14B-7, 12 V / 10.5 Ah
Main fuse:	37.0 A
Headlight fuse:	22.0 A
Radiator fan fuse:	8.5 A

TORQUE SPECIFICATIONS

Spark plug:	22 Nm
Cylinder head bolt:	51 Nm
Oil drain plug:	29 Nm
Rear axle nut:	118 Nm

MAINTENANCE INTERVALS

Engine oil:	every 4500 km
Air filter:	every 9000 km
Coolant:	every 27000 km

Spark plug: every 13500 km

WATER PUMP REMOVAL PROCEDURE

The water pump is located behind the right-side engine cover and is not directly accessible. The following components must be removed in order before the pump can be reached.

- Step a: Remove the right fairing panel (3 bolts, pull outward from the bottom c
- Step b: Drain the coolant by opening the drain bolt on the lower radiator hose.
- Step c: Disconnect the upper and lower radiator hoses from the engine.
- Step d: Remove the radiator (4 mounting bolts, slide forward to clear the frame
- Step e: Remove the exhaust header pipe (2 flange nuts at the cylinder head, 1 c
at the mid-pipe junction).
- Step f: Remove the right engine cover (6 bolts of varying length - note positio
reassembly; cover has a locating dowel at the lower-left corner).
- Step g: Remove the oil pump drive sprocket and chain (1 circlip, slide sprocket
- Step h: The water pump body is now accessible. Remove the 3 pump mounting bolts
pull the pump straight out. Discard the O-ring seal and replace on reas

Reassemble in reverse order. Torque the engine cover bolts to 12 Nm and refill with coolant (capacity 1.83 L). Run the engine and check for leaks.