CT-200 conveyor Configuration B

Document CT200-B | Revision 3 | Issued 1 September 2026

1. Applicability

Applies only to CT-200 configuration B. Confirm the installed configuration in the equipment record. A newer publication date alone does not establish applicability. This fictional conveyor uses a motor, gearbox, drive, belt, support rollers and package sensors.

2. Motor overload

The simulated drive label MOTOR_OVERLOAD means motor protection detected excessive loading over time. The label does not identify a unique failed component. Possible explanations include mechanical resistance or obstruction, motor-related problems, or incorrect motor configuration. A recent product change is context, not proof of cause.

3. Inspection boundary

Use the site-approved maintenance procedure referenced as SITE-M01. Physical checks require authorised staff and the site's isolation and verification process. Review existing observations, including where noise was heard. Binding rollers are one possible source of resistance. If the required detailed procedure is unavailable, consult the maintenance lead. This summary does not supply repair or restart instructions.

4. Replacement reference

For the underside return roller assembly on configuration B, consult the approved parts list: RA-200B, assembly including bearings. RA-200A is not an approved substitute. Stock and reservations must be confirmed separately with stores.

5. Other stops

A conveyor can also stop because a downstream machine is not ready. A production readiness signal is distinct from a safety stop and from a drive-reported motor overload. The records must identify which condition occurred.