

6. インターフェース要件

6.1. WebGUI①画面一覧

6.1.2 トップ画面 ダッシュボード

The screenshot displays a web interface for PTP (Precision Time Protocol) status monitoring. At the top, there's a header with navigation links and a user profile. Below the header, the main content area is divided into several sections:

- PTP状態表示**: A section showing the current PTP status. It includes a lock status indicator (UNLOCKED), GM ID (unknown), Source ID (unknown), and Offset (平均/最大/最小 (ns) 0/0/0).
- 計測ログ(最新100件)**: A table displaying the latest 100 measurement logs. The table has columns for recorded_at, lock_status, gm_id, source_id, offset_avg_ns, offset_max_ns, and offset_min_ns. The data shows a series of measurements with timestamps and various offset values.
- イベントログ(最新100件)**: A section for event logs, currently showing "データがありません" (No data available).
- SENDER ①** and **RECEIVER ①**: Sections for sender and receiver status, both showing "Not Implemented (第2期)".
- SENDER ②** and **RECEIVER ②**: Sections for sender and receiver status, both showing "Not Implemented (第2期)".

On the right side of the dashboard, there are buttons for "CSVエクスポート" (CSV Export) and "ログクリア" (Clear Log).

小さく表示
・機能設定
・システム表示

Sender・Receiver領域
をドラッグで上下に拡大
縮小できるようにする

全体を100%で表示で
きるようにする

6. インターフェース要件

6.1. WebGUI画面一覧

6.1.3 画面遷移イメージ



設定変更 GUI

WebGUI②

⊙ ダッシュボードGUIへの遷移

PTP設定

システム設定

PTP設定

ドメイン番号	127
Priority1	128
Priority2	128
Sync Interval (log2 sec)	-3
Announce Interval (log2 sec)	0
Delay Request Interval (log2 sec)	-3
ロック判定・アラート閾値	
ロック閾値(ns)	500
ロック安定時間(秒)	3
Offsetアラート閾値(ns)	500
保存 ログのクリア	

保存するとPTPコンテナ(コンテナ②)を再起動します。

⊙ ダッシュボードGUIへの遷移

PTP設定

システム設定

システム設定

NIC割り当て

NIC①(Amber・メディア)	eth0
NIC②(Blue・メディア・オプション)	eth1
NIC③(制御)	eth2

保存

保存すると本システムを再起動します。

IPアドレス設定

インターフェース	eth2
DHCP	☐
IPアドレス(CIDR)	192.168.1.10/24
デフォルトゲートウェイ	192.168.1.1

保存

保存するとサーバーOSを再起動します。

設定エクスポート・インポート

エクスポート インポート

システム設定(NIC割り当て・IPアドレス)を除く全設定が対象です。

電源操作

本システム再起動 サーバーOS再起動 サーバーシャットダウン