



CCC26 MESH — M2 COMMUNITY NODE

Off-grid communications — no internet required

FOR BYOD USERS

Bring your own Meshtastic device

Have your own Meshtastic device? Scan to join.

Loaner devices are already configured — no setup needed.

1. Install Meshtastic app (Android or iPhone)
2. Pair your device via Bluetooth in the app
3. Scan the QR — channel imports automatically
4. Settings → User: enter your name or handle
5. Tap CCC26 channel to send a message



Channel: CCC26 — Region: US — LongFast — Airplane mode OK, keep BT on

CUT



CCC26 MESH — M2 COMMUNITY NODE

Off-grid communications — no internet required

FOR BYOD USERS

Bring your own Meshtastic device

Have your own Meshtastic device? Scan to join.

Loaner devices are already configured — no setup needed.

1. Install Meshtastic app (Android or iPhone)
2. Pair your device via Bluetooth in the app
3. Scan the QR — channel imports automatically
4. Settings → User: enter your name or handle
5. Tap CCC26 channel to send a message



Channel: CCC26 — Region: US — LongFast — Airplane mode OK, keep BT on